



Kids’ ski size chart

Stand the ski on its tail: it should reach between the child’s chest and nose.
Nearer the chest for beginners, nearer the nose for heavier or confident kids.

Age	Height	Weight	cm · kg	Ski length
4	3'4"	35 lb	102 · 16	80–90 cm
6	3'9"	46 lb	114 · 21	95–105 cm
8	4'2"	57 lb	127 · 26	110–120 cm
10	4'7"	71 lb	140 · 32	120–130 cm
12	4'11"	90 lb	149 · 41	135–145 cm
14	5'5"	112 lb	164 · 51	150–160 cm

Go by size, not age

Height and weight matter more than age.

Don’t buy long to grow into

Long skis are harder to turn and less fun (evo).

Sources: evo kids’ ski sizes. Checked 30 Oct 2026. Sizes are guidance: check the brand’s chart for the exact model.